

Sparco Suit Size Chart

Sizes listed are for body measurements, not of the suit. If height and weight do not correspond, then choose the size corresponding to your height

Sparco Size	46	48	50	52	54	56	58	60	62	64	66
		XS	S	S	M	L	L	XL			
Chest (cm)	88/92	92/96	96/100	100/104	104/108	108/112	112/116	116/120	120/124	124/128	128/132
Waist (cm)	76/79	80/84	85/88	89/92	93/96	97/100	101/105	106/110	111/114	115/119	120/123
Hips (cm)	89/92	93/96	97/100	101/104	105/108	109/112	113/117	118/122	123/126	127/130	131/134
Height (cm)	164/170	170/176	170/176	176/178	176/182	182/188	182/188	188/194	188/194	194/200	200/206
Weight (kg)	56/60	61/66	67/72	73/78	79/84	85/90	91/96	97/102	103/108	109/114	115/120

